



Packaging Instructions for Returning StoveTop FireStop® or Range Queen Fire Suppressors

If your original packaging materials are unavailable, follow these instructions to return your Range Queen and/or StoveTop FireStop® Automatic Fire Suppressors.

A. Returns by Corrugated Box

1. Use a corrugated box with an established weight rating.
2. Use less than 75 percent of the weight capacity of the box. Each StoveTop FireStop weighs approximately 12 oz.
3. Line the corrugated box with a plastic material to prevent leakage in the event a StoveTop FireStop is broken. A standard trash bag—approximately 1.2 mil. thick—should suffice.
4. Fill the box with the StoveTop FireStops by placing each on its side (label), end-to-end (lid-to-lid).
5. Once you fill the box, fill any remaining voids with packaging material (such as styrofoam peanuts) and seal the box closed with standard packaging tape. Seal all exposed corners and edges with tape to prevent potential leakage.

StoveTop FireStop is U.S. DOT exempt; therefore, no special labeling or further packaging is required.

B. Returns by Barrel

1. Use a plastic or metal shipping barrel with an established weight rating.
2. Use less than the weight capacity of the barrel. Each StoveTop FireStop weighs approximately 12 oz. **For volume reference only**, approximately 120 StoveTop FireStops will fit into a 30 gallon barrel.
3. Fill the box with the StoveTop FireStops by placing each on its side (label), end-to-end (lid-to-lid).
4. Once you fill the barrel, properly secure the barrel to prevent leakage. No special labeling or further packaging is required.

Address units to:

Williams-Pyro, Inc.
200 Greenleaf Street
Fort Worth, Texas 76107